

Crankshaft

	Std	Crank 010	Crank 020	Crank 030
Std Bore				
	111198461	111198463	111198465	111198467
	std crank	010 crank	020 crank	030 crank
	no line bore	no line bore	no line bore	no line bore
20 Line Bore				
	111198471	111198473	111198475	111198447
	std crank	010 crank	020 crank	030 crank
	20 line bore	20 line bore	20 line bore	20 line bore
	111198471OS	111198473OS	111198475OS	111198447OS
	std crank	010 crank	020 crank	030 crank
	20 line bore	20 line bore	20 line bore	20 line bore
	40 thrust	40 thrust	40 thrust	40 thrust
	111198471X2	111198473X2		
	std crank	010 crank		
	20 line bore	20 line bore		
	80 thrust	80 thrust		
40 Line Bore				
	111198481	111198483	1111984485	1111984487
	std crank	010 crank	020 crank	030 crank
	40 line bore	40 line bore	40 line bore	40 line bore
	111198481OS	111198483OS	111198485OS	111198487OS
	std crank	010 crank	020 crank	030 crank
	40 line bore	40 line bore	40 line bore	40 line bore
	40 thrust	40 thrust	40 thrust	40 thrust
	111198481X2	111198483X2	111198485X2	
	std crank	010 crank	020 crank	
	40 line bore	40 line bore	40 line bore	
	80 thrust	80 thrust	80 thrust	
60 Line Bore				
	11119849160	11119849360	1111984560	1111984560
	std crank	010 crank	020 crank	030 crank
	60 line bore	60 line bore	60 line bore	60 line bore
	80 thrust	80 thrust	80 thrust	80 thrust
80 Line Bore				
	11119849180	11119849380	11119849580	11119849780
	std crank	010 crank	020 crank	030 crank
	80 line bore	80 line bore	80 line bore	80 line bore
	80 thrust	80 thrust	80 thrust	80 thrust